

THE PROTECTOR®

Moisture Meter MT201

by
INNOVATIVE
—tool and design inc.—



FEATURES:

- Measures moisture content from 6% to 22%
- Low Battery and Power indicators
- Protective Cover fits on end of instrument
- Quick response
- Accuracy: $\pm 2\%$
- Operating Temperature: 0–50°C
- Operating Humidity: < 90% R.H.

MOISTURE READINGS:

Green: 6%–10% indicates "air-dry" conditions.

Yellow: 13%–16% indicates increased moisture.

Red: 18%–22% indicates excess moisture.

OPERATION:

1. Remove the protection Cap from the unit.
2. Press the center button to turn the unit on. The power LED will illuminate.
3. Press the two pins firmly against surface to be measured.
4. LED's will illuminate to indicate % moisture content of the material being measured.

WARNINGS:

- REPLACE THE BATTERY WHEN THE "Low-Battery LED" GLOWS OR IF THE UNIT DOES NOT TURN ON.
- REPLACE THE PIN PROTECTION CAP AFTER USE.
- SHARP POINTS. KEEP AWAY FROM CHILDREN.



Innovative Tool and Design, Inc.
10725 Capital St. Oak Park
MI 48237 USA
www.shoptheprotector.com
www.innovativetoolanddesign.com/medical